

IDENTIFICATION OF TREATMENT NEEDS AND TECHNOLOGIES

FOR

EG&G ROCKY FLATS, INC.

BY

IT CORPORATION

JULY, 1990

Best Available Copy

ADMIN RECORD SW-SW-A-03039

#### TREATMENT NEEDS

\* Maintain off-site discharges from Ponds A-4, B-5, and C-2 at <= standards for the following:</p>

### <u>Radionuclides</u>

Plutonium	.05	Picocuries/Liter
Americium	.05	Picocuries/Liter
Tritium	500	Picocuries/Liter
Uranium	10	Picocuries/Liter

### Gross Alpha and Beta

Alpha	11	Picocuries/Liter
Beta	19	Picocuries/Liter

- \* Develop treatment technologies that are effective and most easily understood and accepted by the local community.
- \* Utilize existing carbon adsorption units (if possible) to reduce organic levels to standards. Develop other treatment technologies if necessary.
- \* Size system to treat 1,000 to 1,500 gallons/minute for Ponds A-4 and B-5. Size system to treat 600 to 750 gallons per minute for Pond C-2.
- \* Minimize waste generation in meeting discharge standards.
- \* Minimize impact on environment resulting from installation of treatment system.

#### **ASSUMPTIONS**

- 1) Discharges from Pond C-2 will be diverted from the Woman Creek Drainage to the Walnut Creek Drainage. Therefore, standards applicable to Walnut Creek will be established as standards for discharge from C-2.
- 2) Wastes generated as a result of pond water treatment will be handled as low-level waste.
- 3) Alpha and Beta standards will be met when the radionuclides listed below are reduced to standards.

Plutonium Americium Uranium

4) Treatment technologies will be developed that have a minimal need for additives.

#### TECHNOLOGIES

### Flocculation / Coagulation

- \* Alum
- \* Ferric Sulfate
- \* Clay (montmorillonite)
- \* Lamella Clarifier

### Sludge Dewatering

- \* Belt Filter
- \* Drum Filter
- \* Filter Press

## Clarifier Effluent Polishing

- \* Cartridge Filters
- \* Bag Filters
- \* Sand Filters

### Dissolved Material Removal


- \* Reverse Osmosis
- \* Ultrafiltration
- \* Carbon Adsorption

#### Ion Exchange

- \* Ionac A641
- \* Dowex 21K

### Incineration / Stabilization

- \* Incineration / Air Pollution Control
- \* Cementation



### SUMMARY OF EFFECTIVENESS OF TREATMENT METHODS FOR URANIUM REMOVAL (1)

TREATMENT METHOD	OBSERVED PERCENT REMOVAL	CONDITIONS
Iron coagulation	80 - 85	pH 6 & 10
Alum coagulation	90 - 95	рН 10
-	80 - 85	рн 6
Lime softening	99	рн 10.6
Ion exchange	99	10k-50k BV
Granular activated carb	on 90+	Limit.Cap
Reverse osmosis	99	none

#### Notes:

Under ion exchange, BV refers to bed volumes treated before breakthrough occurs. Typical initial uranium concentrations were 100 picocuries/liter

All of the above technologies were tested against inlet concentrations of uranium ranging from approximately 30 to 150 picocuries/liter.

(1) Sorg, T. J., Methods for Removing Uranium From Drinking Water, EPA/600/J-88/134, Cincinnati, OH, 1988

#### DATA NEEDS & SUGGESTED TESTS

- 1) Concentration of non-volatile suspended solids (summer level)
- 2) Pond water pH for Ponds A-4, B-5, and C-2 Are pH values variable with the seasons?
- 3) Reductions (if any) in concentrations of radionuclides attributed to the operation of the existing treatment system (i.e. effectiveness of carbon adsorption and filter bags).
- 4) Identification of sources of the radionuclides of concern.

#### **DEFINITIONS**

- 1) COAGULATION charge neutralization; addition of coagulant typically reduces the net repulsive (like) charges associated with particles in a liquid.
- 2) FLOCCULATION term generally includes the process of coagulation; refers to the growth of particles in dilute slurries which assists in subsequent sedimentation and filtration
- 3) LAMELLA CLARIFIER baffled tank designed to assist in the settling of suspended solids in a liquid.
- 4) SLUDGE DEWATERING solid/liquid separation process capable of providing a sludge cake consisting of approximately 30% solids and 70% liquid.
- 5) CLARIFIER EFFLUENT POLISHING process capable of removing particulates (down to approximately 0.45 microns) from a liquid.
- 6) REVERSE OSMOSIS (RO) use of selective membrane that allows passage of water molecules but prevents passage of ions such as salts Operating pressures for effective RO range from 200 to 1,200 psig.
- 7) ULTRAFILTRATION (UF) use of membrane to retain small particles and large molecules. Allows passage of salts, small molecules, and water.